


# PARTS & INSTRUCTION MANUAL NC-15L

N-C CARPET BINDING  
& EQUIPMENT CORP.  
858 SUMMER AVE.  
NEWARK, NJ 07104  
PHONE (973) 481-3500  
TOLL FREE (800) 526-1184  
FAX (973) 481-0839  
EMAIL: SALES@NCCARPET.COM  
WWW.NCCARPET.COM



NOTE: Read safety instructions carefully and understand them before using.  
Retain this Instruction Manual for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

Putting sewing systems into operation is prohibited until it has been ascertained that the sewing systems in which these sewing machines will be built into, have conformed with the safety regulations in your country.

Technical service for those sewing systems is also prohibited.

1. Observe the basic safety measures, including, but not limited to the following ones, whenever you use the machine.
2. Read all the instructions, including, but not limited to this Instruction Manual before you use the machine. In addition, keep this Instruction Manual so that you may read it at anytime when necessary.
3. Use the machine after it has been ascertained that it conforms with safety rules/standards valid in your country.
4. All safety devices must be in position when the machine is ready for work or in operation.  
The operation without the specified safety devices is not allowed.
5. This machine shall be operated by appropriately – trained operators.
6. For your personal protection, we recommend that you wear safety glasses.
7. For the following, turn off the power switch or disconnect the power plug of the machine from the receptacle.
  - 7 – 1 For threading needle (s), looper, spreader etc. and replacing bobbin.
  - 7 – 2 For replacing part (s) of needle, presser foot, throat plate, looper, spreader, feed dog, needle guard, folder, cloth guide etc.
  - 7 – 3 For repair work.
  - 7 – 4 When leaving the working place or when the working place is unattended.
  - 7 – 5 When using clutch motors without applying brake, it has to be waited until the motor stopped totally.
8. If you should allow oil, grease, etc. used with the machine and devices to come in contact with your eyes or skin or swallow any of such liquid by mistake, immediately wash the contacted areas and consult a medical doctor.

9. Tampering with the live parts and devices, regardless of whether the machine is powered, is prohibited.
10. Repair, remodeling and adjustment works must only be done by appropriately trained technicians or specially skilled personnel. Only spare parts designated by us can be used for repairs.
11. General maintenance and inspection works have to be done by appropriately trained personnel.
12. Repair and maintenance works of electrical components shall be conducted by qualified electric technicians or under the audit and guidance of specially skilled personnel.  
Whenever you find a failure of any of electrical components, immediately stop the machine.
13. Before making repair and maintenance works on the machine equipped with pneumatic parts such as an air cylinder, the air compressor has to be detached from the machine and the compressed air supply has to be cut off. Existing residual air pressure after disconnecting the air compressor from the machine has to be expelled. Exceptions to this are only adjustments and performance checks done by appropriately trained technicians or specially skilled personnel.
14. Periodically clean the machine throughout the period of use.

15. Grounding the machine is always necessary for the normal operation of the machine. The machine has to be operated in an environment that is free from strong noise sources such as high – frequency welder.
16. An appropriate power plug has to be attached to the machine by electric technicians. Power plug has to be connected to a grounded receptacle.

17. The machine is only allowed to be used for the purpose intended. Other used are not allowed.
18. Remodel or modify the machine in accordance with the safety rules/standards while taking all the effective safety measures. assumes no responsibility for damage caused by remodeling or modification of the machine.

19. Warning hints are marked with the two shown symbols.





Danger of injury to operator or service staff




Items requiring special attention



## FOR SAFE OPERATION

	<ol style="list-style-type: none"> <li>1. Keep your hands away from needle when you turn ON the power switch or while the machine is in operation.</li> <li>2. Do not put your fingers into the thread take – up cover while the machine is operating.</li> <li>3. Turn OFF the power switch when tilting the machine head, or removing the belt cover or the V belts.</li> <li>4. During operation, be careful not to allow your or any other person’s head, hands or clothes to come close to the handwheel, V belt and motor, Also, do not place anything close to them.</li> <li>5. Do not operate your machine with the belt cover and finger guard removed.</li> <li>6. When tilting the machine head, be sure to confirm that the head support bar is properly attached to your machine head, and be careful not to allow your fingers or the like to be pinched in the machine head. In addition, when the machine is used with the control panel, do not tilt or raise the machine head while holding the control panel.</li> </ol>
	<ol style="list-style-type: none"> <li>1. To ensure safety, never operate the machine with the ground wire for the power supply removed.</li> <li>2. When inserting/removing the power plug, the power switch has to be turned OFF in advance.</li> <li>3. In time of thunder and lightening. stop your work and disconnect the power plug from the receptacle so as to ensure safety.</li> <li>4. If the machine is suddenly moved from a cold place to a warm place, dew condensation may be observed. In this case, turn ON the power to the machine after you have confirmed that there is no danger of water drops in the machine.</li> </ol>

**CAUTION:**


 Note that safety devices such as “eye guard”, “finger guard”, etc. may be omitted from the illustrations in this Instruction Manual for easy explanation.  
 When operating the machine, be sure not to remove these safety devices.

## CONTENTS

BEFORE OPERATION .....	1
SPECIFICATIONS .....	1
1. INSTALLATION .....	2
2. INSTALLING THE WASTE OIL CONTAINER .....	3
3. ADJUSTING THE BELT TENSION .....	3
4. ATTACHING THE BELT COVER .....	4
5. LUBRICATION .....	5
6. ATTACHING THE NEEDLE .....	7
7. ATTACHING/REMOVING THE BOBBIN .....	7
8. THREADING THE HOOK .....	7
9. INSTALLING THE BOBBIN WINDER THREAD GUIDE .....	8
10. WINDING A BOBBIN .....	8
11. THREADING THE MACHINE HEAD .....	8
12. ADJUSTING THE STITCH LENGTH .....	9
13. THREAD TENSION .....	9
14. THREAD TAKE – UP SPRING .....	10
15. HAND LIFTER .....	10
16. ADJUSTING THE PRESSURE OF THE PRESSER FOOT .....	10
17. NEEDLE – TO – HOOK RELATION .....	10
18. ADJUSTING THE HOOK NEEDLE GUARD .....	11
19. ADJUSTING THE BOBBIN CASE OPENING LEVER .....	11
20. ADJUSTING THE LIFTING AMOUNT OF THE PRESSER FOOT AND THE WALKING FOOT ...	12
21. SEWING SPEED TABLE .....	12
22. MOTOR PULLEY AND V BELT .....	12
23. RESETTING THE SAFETY CLUTCH .....	13
24. TROUBLES IN SEWING AND CORRECTIVE MEASURES .....	13

## BEFORE OPERATION



### CAUTION:

Check the following so as to prevent maloperation of and damage to the machine.



- Before you put the machine into operation for the first time after the set – up, clean it thoroughly. Remove all dust gathering during transportation and oil it well.
- Confirm that the voltage has been correctly set.  
Confirm that the power plug has been properly connected to the power supply.
- Never use the machine in the state where the voltage type is different from the designated one.
- The direction of normal rotation of the machine is counterclockwise as observed from the pulley side. Take care not to allow the machine to rotate in the reverse direction.
- When tilting the machine head, tilt it after removing knee lifter hook.
- Never operate the machine unless the head base has been tilted with oil.
- For a test run, remove the bobbin and the needle thread.
- For the first month, decrease the sewing speed and run 1508N at a speed of 2000 rpm or less and 1508NH 1600 rpm or less.
- Operate the handwheel after the machine has totally stopped.

## SPECIFICATIONS

Model	1560
Sewing speed	Max. 2500 rpm See "21. SEWING SPEED TABLE" on page 12.
Stitch length (max. )	Normal feed: 9mm    Reverse feed: 9mm
Needle	SCHMETZ 135 × 17(Nm 125 to Nm 180) (Standard: Nm 160)
Thread	#30 to #5(US: #46 to #138, Europe: 20/3 to 60/3)
Hook	Vertical – axis 2.0 – fold capacity hook
Lift of presser foot	Hand lifter lever: 9mm
	Knee lifter: 16mm
Lubricating oil	New Defrix Oil No. 2
Noise	Workplace – related noise at sewing speed $n = 1550 \text{ min}^{-1}$ : $L_{PA} \leq 84 \text{ dB(A)}$ Noise measurement according to DIN 45635 – 48 – A – 1.




# 1. INSTALLATION



## 1) Attaching the hinge seats and the support rubbers of the machine head


Fix the hinge seats ① and the support rubbers ② supplied with the machine on the table using nails ③ .

If the slide plate comes in contact with the table when opening it, place spacer rubbers ④ and ⑤ supplied with the machine under support rubbers ② and hinge seats ① .



## 2) Attaching the oil pan


Fix the oil pan ① supplied with the machine by tightening eight wood screws.



3) Adjust knee pad joint ①, knee lifter vertical shaft installing arm ② and knee pad lever ③ to the direction of knee lifter lever shaft ④ and assemble these components.

4) Adjust the direction of the pad with setscrews ⑤, ⑥ and ⑦ .

## 2. INSTALLING THE WASTE OIL CONTAINER




- 1) Attach drain plug ①, oil seal ② and washer ③ to the oil pan. Attach packing ⑤ and washer ⑧ to screw ④ and fix them with nut ⑥.
- 2) After they are fixed, screw in waste oil container ⑦ into drain plug ①.

## 3. ADJUSTING THE BELT TENSION



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



Adjust the belt tension with the height of the motor so that the belt sags 15 mm when the center of V belt is applied with a 9.8 N load.




## 4. ATTACHING THE BELT COVER



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



- 1) Attach belt cover stud (7) to the screw hole in the arm.
- 2) Fix belt cover (right) (1) on the arm with screws (2) and (8).
- 3) Fit belt cover (left) (3) to notch (A) and (B) of the belt cover (right).
- 4) Fix belt cover (left) (3) with screws (4), (5) and (6).
- 5) Fix belt cover auxiliary plate (8) at the position of 10 mm from the rear end with wood screws (9) when there is a clearance of 2.5 mm between the belt cover and the auxiliary plate.
- 6) When tilting the machine head, loosen wood screws (9) and move the belt cover auxiliary plate in the direction of the arrow until it stops. Then, tilt the machine head.




After attaching the belt cover, confirm whether or not the respective cords do not come in contact with the belt and the handwheel. Disconnection of the cords will result when they come in contact with one another.

## 5. LUBRICATION



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.




1) Prior to operation, apply an adequate amount of oil once a day to the points marked with the arrows ① .

Prior to operation, apply one drop of oil once a day to the point marked with the arrow ② .

You can apply oil to the point marked with ① after removing the rubber cap without removing the face plate.

2) When you operate your machine for the first time after the set - up or after an extended period of disuse, apply an adequate amount of oil to the points marked with the arrows and to each felt and oil wick after removing top cover ① .



3) Insert the projection located at the bottom of oil tank ① into the waste oil hole of the oil pan.

4) Insert oil pipe ② into filter ③ of the oil tank and fix the pipe with a clip.


5) Pour the New Defrix Oil No. 2 into the oil tank until HIGH level is reached.

6) Add the same lubricating oil up to HIGH level as soon as the oil level has come down to LOW level.

7) After the lubrication, you can see from oil sight window ⑤ that the oil rises up when the operation is normal.

(However, the machine should run at 1500 rpm or more.)





### ■ Cleaning the oil tank

1. Remove the oil pipe from oil tank ① .
2. Remove butterfly nut ⑥ and take out cover (upper) ⑦, filter ⑧ and cover (lower) ⑨ to clean the oil tank.
3. Remove filter case setscrews ⑩, and clean filter element ⑪ located on the inside of the filter case and magnet ⑫ .

#### (Caution)

Approximately once a month, clean the oil tank and the filter case.


If the filter is clogged with soil, lubrication fails resulting in trouble.

4. When replacing the oil in the oil tank, remove stopper ⑬ in the oil tank. Then, the oil can be drained from the installing port of the waste oil container in the oil pan. After draining, securely set stopper ⑬ to the oil tank. When taking out the oil tank take it out after draining the oil.

5. Fix the filter case in which filter element ⑪ and magnet ⑫ are placed to cover (upper) ⑦ with setscrews ⑩ .

6. Place cover (lower) ⑨, filter ⑧ and cover (upper) ⑦ in order in the oil tank, and fix them with butterfly nut ⑥ .

7. Insert the oil pipe into the oil tank and fix it with a clip. Fill the oil tank with New Defrix Oil No. 2 up to HIGH level.



- 8) Loosen nut ⑮ and turn oil amount adjustment screw ⑭ to adjust the amount of oil in the hook.

Turning the screw clockwise ① will decrease the amount of oil in the hook or counterclockwise ② will increase it.


- 9) The appropriate amount of oil, when a sheet of paper is placed near the periphery of the hook, is to such an extent that splashes of oil from the hook appear in approximately five seconds as shown in the figure on the left.

## 6. ATTACHING THE NEEDLE



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



- 1) Turn the handwheel to bring the needle bar to the highest position of its stroke.
- 2) Loosen needle clamp screws ②, and hold needles ① so that the long grooves in the needles come inside respectively.
- 3) Push needles ① deep into the needle clamp holes until they will go no further.
- 4) Tighten needle clamp screws ② firmly.

(Caution)

When replacing the needle, check the clearance provided between the needle and the blade point of hook. (Refer to "17. NEEDLE - TO - HOOK RELATION" and "18. ADJUSTING THE HOOK NEEDLE GUARD".)


If there is no clearance, the needle and the hook will be damaged.

## 7. ATTACHING AND REMOVING THE BOBBIN



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



- 1) Lift latch ① of hook, and take out the bobbin.
- 2) Put the bobbin into the shaft in the hook correctly and release the latch.

(Caution)


1. Do not make the machine run idle with the bobbin (bobbin thread). The bobbin thread is caught in the hook. As a result, the hook may be damaged.
2. Be careful so as not to get hurt with the top end of the counter knife.

## 8. THREADING THE HOOK



### WARNING:


To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



- 1) Pass the thread through thread path ① in the hook and thread hole ② in the lever, and draw the thread. Now, the thread will be brought to thread hole ② via the tension spring.
- 2) Make sure that the bobbin revolves in the direction of the arrow when you draw the thread.




## 9. INSTALLING THE BOBBIN WINDER THREAD GUIDE



- 1) Attach bobbin winder thread guide ① to the top cover using screws ② .
- 2) Adjust the position of the thread guide referring to "10. WINDING A BOBBIN".
- 3) Strike bobbin thread guide rod ③ into the machine arm.

## 10. WINDING A BOBBIN




- 1) Pass the thread in the order of ①, through ④ .  
Then, wind it several turns round the bobbin.
- 2) Tilt bobbin winder lever ① .
- 3) Loosen setscrew ② and adjust the position of the adjusting plate to wind a bobbin about 80% of its capacity.
- 4) If the bobbin is wound unevenly, correct it by moving bobbin winder thread guide ③ back or forth.  
Then, tighten setscrews ④ .
- 5) When the bobbin is filled up, the bobbin winder lever automatically releases the bobbin and the bobbin winder stops running.

## 11. THREADING THE MACHINE HEAD




### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



1. Attach arm thread guide ① to the top cover with setscrew ② .
2. Pass the left - hand needle thread in the order of ① to ⑭ ⑮ .  
Pass the right - hand needle thread in the order of ① to N ( O ) as illustrated in the figure.

## 12. ADJUSTING THE STITCH LENGTH



Turn stitch dial ① counterclockwise (clockwise) so that the number corresponding to the desired stitch length is brought to the top until the marking spot is reached.


(1) Reverse feed stitching

1) Press down reverse feed control lever ② .

2) Reverse feed stitches are made as long as you keep pressing the lever down.

3) Release the lever, and the machine will run in the normal feed direction.

## 13. THREAD TENSION



(1) Adjusting the needle thread tension


1) Turn thread tension nut No. 1 ① clockwise ① to shorten the length of thread remaining on the top of needle after thread trimming. Turn the nut counterclockwise ② to lengthen it.

2) Turn thread tension nut No. 2 ② clockwise ① to increase the needle thread tension, or counterclockwise ② to decrease it.



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



(2) Adjusting the bobbin thread tension

Turn tension adjustment screw ③ clockwise ① to increase the bobbin thread tension, or counterclockwise ② to decrease it.




## 20. ADJUSTING THE LIFTING AMOUNT OF THE PRESSER FOOT AND THE WALKING FOOT



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



The amount of alternate vertical movement of the presser foot and the walking foot is normally equal. To increase the amount of alternate vertical movement, move upper feed arm ① upward in the range of the slot.

To decrease it, move the upper feed arm downward. Then, tighten the nut ③.

To change the lifting amount of the presser foot and that of the walking foot, loosen screw ② in the upper feed arm, turn the handwheel to this side and tighten screw ② when the bottom faces of the presser foot and the walking foot are flush at the top surface of the throat plate.

Then, the lifting amount of the presser foot becomes more than that of the walking foot. Or, turn the handwheel in the reverse direction to increase the lifting amount of the walking foot more than that of the presser foot.

You will find upper feed arm O when removing the right side of the window, plate.

Standard of the amount of alternate vertical movement	
Engraved marker line ①	Aprox. 5mm
Engraved marker line ②	Aprox. 4mm
Engraved marker line ③	Aprox. 3mm

## 21. SEWING SPEED TABLE

The maximum sewing speed has been specified in accordance with sewing conditions as shown in the table below. Set the maximum sewing speed appropriately in accordance with the sewing conditions given taking care not to exceed the corresponding specified value.

1) Maximum sewing speed in accordance with the amount of alternate vertical movement of the walking foot and presser foot

Amount of alternate vertical movement of the walking foot and presser foot	Stitch length: 6 mm or less	Stitch length: More than 6 mm and 9 mm or less
Less than 3 mm	2500 rpm	2000 rpm
3 mm to less than 4 mm	2000 rpm	2000 rpm
4 mm to less than 6.5 mm	1600 rpm	1600 rpm

2) Maximum sewing speed in accordance with the needle gauge

Needle gauge	Max. Sewing speed
3.2mm(1/8) to 9.5mm(3/8)	2500 rpm
12.7mm(1/2) to 19.1mm(3/4)	2000 rpm
22.2mm(7/8) to 31.8mm(1-1/4)	1600 rpm

## 22. MOTOR PULLEY AND V BELT

Use an M type V belt.

The following table shows the relationship among the motor pulley, belt length and the rotational speed of the sewing machine.

Rotational speed of sewing machine	Effective diameter of handwheel	Number of poles	Frequency	Rotational speed of motor	Effective diameter of motor pulley	Size of V belt
2500 rpm	φ 93.3mm	2	50Hz	2840rpm	φ 80	M 44
			60Hz	3400 rpm	φ 65	M 43
		4	50Hz	1430 rpm	φ 160	M 47
			60Hz	1715 rpm	φ 135	M 46


For the motor, use a 2P or 4P clutch motor of 3-phase 400W (1/2 HP).

## 23. RESETING THE SAFETY CLUTCH



### WARNING:

To avoid possible personal injury due to abrupt start of the machine, turn off the power to the machine and check to be sure that the motor has totally stopped rotating in prior.



The safety clutch functions when an excessive load is applied to the hook or the other components during sewing. At this time, the hook will never rotate even if turning the handwheel.

When the safety clutch has functioned, remove the cause and reset the safety clutch as given in the following procedure.


- 1) Pressing push button ① located on the top surface of the machine bed, strongly turn the handwheel in the reverse direction of rotation.
- 2) The resetting procedure completes when the handwheel clicks.

## 24. TROUBLES IN SEWING AND CORRECTIVE MEASURES

Troubles	Causes	Corrective measures
1. Thread breakage (Thread frays or is worn out.)  (Needle thread trails 2 to 3 cm from the wrong side of the fabric.)	<ol style="list-style-type: none"> <li>① Thread path, needle point, hook blade point or bobbin case resting groove on the throat plate has sharp edges or burrs.</li> <li>② Needle thread tension is too high.</li> <li>③ Bobbin case opening lever provides an excessive clearance at the bobbin case.</li> <li>④ Needle comes in contact with the blade point of hook.</li> <li>⑤ Amount of oil in the hook is too small.</li> <li>⑥ Needle thread tension is too low.</li> <li>⑦ Thread take-up spring works excessively or the stroke of the spring is too small.</li> <li>⑧ Timing between the needle and the hook is excessively advanced or retarded.</li> </ol>	<ul style="list-style-type: none"> <li>○ Remove the sharp edges or burrs on the blade point of hook using a fine emery paper. Buff up the bobbin case resting groove on the throat plate.</li> <li>○ Decrease the needle thread tension.</li> <li>○ Decrease the clearance provided between the bobbin case opening lever and the bobbin. Refer to "19. ADJUSTING THE BOBBIN CASE OPENING LEVER."</li> <li>○ Refer to "17. NEEDLE - TO - HOOK RELATION."</li> <li>○ Adjust the amount of oil in the hook properly. Refer to "5. LUBRICATION".</li> <li>○ Increase the needle thread tension.</li> <li>○ Decrease the tension of the spring and increase the stroke of the spring.</li> <li>○ Refer to "17. NEEDLE - TO - HOOK RELATION."</li> </ul>
2. Stitch skipping	<ol style="list-style-type: none"> <li>① Timing between the needle and the hook is excessively advanced or retarded.</li> <li>② Pressure of the presser foot is too low.</li> <li>③ The clearance provided between the top end of the needle eyelet and the blade point of hook is not correct.</li> <li>④ Hook needle guard is not functional.</li> <li>⑤ Improper type of needle is used.</li> </ol>	<ul style="list-style-type: none"> <li>○ Refer to "17. NEEDLE - TO - HOOK RELATION."</li> <li>○ Tighten the presser spring regulator.</li> <li>○ Refer to "17. NEEDLE - TO - HOOK RELATION."</li> <li>○ Refer to "18. ADJUSTING THE HOOK NEEDLE GUARD."</li> <li>○ Replace the needle with one which is thicker than the current needle by one count.</li> </ul>
3. Loose stitches	<ol style="list-style-type: none"> <li>① Bobbin thread does not pass through the tension spring of the inner hook.</li> <li>② Thread path has been poorly finished.</li> <li>③ Bobbin fails to move smoothly.</li> <li>④ Bobbin case opening lever provides too much clearance at the bobbin.</li> <li>⑤ Bobbin thread tension is too low.</li> <li>⑥ Bobbin has been wound too tightly.</li> </ol>	<ul style="list-style-type: none"> <li>○ Thread the bobbin thread correctly.</li> <li>○ Remove rough parts with a fine emery paper or buff it up.</li> <li>○ Replace the bobbin or hook with a new one.</li> <li>○ Refer to "19. ADJUSTING THE BOBBIN CASE OPENING LEVER."</li> <li>○ Increase the bobbin thread tension.</li> <li>○ Decrease the tension applied to the bobbin winder.</li> </ul>
4. Thread slips off the needle eyelet at the start of sewing.	<ol style="list-style-type: none"> <li>① Thread tension given by the tension controller No. 1 is too high.</li> <li>② Clamp spring has improper shape.</li> <li>③ Bobbin thread tension is too low.</li> </ol>	<ul style="list-style-type: none"> <li>○ Decrease the thread tension given by the tension controller No. 1.</li> <li>○ Replace the clamp spring with a new one or correct the current one.</li> <li>○ Increase the bobbin thread tension.</li> </ul>



# 1. FRAME & MISCELLANEOUS COVER COMPONENTS






# 1. FRAME & MISCELLANEOUS COVER COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 0101	FACE PLATE ASM.	1	
2	23 - 0102	SCREW	3	SM11/64" x 40 L = 12
3	23 - 0103	RUBBER	2	
4	24 - 0104	TOP COVER	1	
5	23 - 0105	SCREW	13	SM11/64" x 40 L = 8
6	23 - 0106	ARM THREAD GUIDE	1	
7	23 - 0107	SCREW	2	SM3/16" x 32 L = 9.5
8	23 - 0108	WINDOW PLATE A ASM.	1	
9	24 - 0148	SCREW	1	SM3/16" x 32 L = 12
10	23 - 0111	SETSCREW	1	SM11/64" x 40 L = 7.5
11	23 - 0112	WINDOW PLATE B	1	
12	23 - 0113	WINDOW PLATE PACKING B	1	
13	23 - 0151	OIL SHIELD (LEFT)	1	
14	23 - 0115	RUBBER PLUG	2	
15	23 - 0116	SIDE COVER	1	
16	23 - 0152	DUST COVER	1	
17	24 - 0118	THREAD GUIDE, B	1	
18	23 - 0119	SCREW 15/64 - 28 L = 9	1	SM15/64" x 28 L = 9
19	23 - 0120	THREAD GUIDE, B	1	
20	23 - 0123	SCREW	5	SM9/64" x 40 L = 5.6
21	23 - 0122	FRAME THREAD GUIDE, UPPER	1	
22	23 - 0124	THREAD GUIDE ASM.	1	
23	23 - 0170	SCREW	2	SM9/64" x 40 L = 3.2
24	23 - 0168	AUXILIARY COVER	1	
25	23 - 0169	SLIDING PLATE PRESSER	1	
26	24 - 0140	BED SLIDE, LEFT	1	
27	23 - 0138	SCREW	1	SM9/64" x 40 L = 6
28	23 - 0137	SCREW	1	SM11/64" x 40 L = 7
29	24 - 0142	BED SLIDE, RIGHT	1	
30	24 - 0136	THROAT PLATE	1	
31	23 - 0143	BED SLIDE ASM.	1	
32	23 - 0132	TAKE - UP SPRING ADJUSTING PLATE	1	
33	23 - 0133	SCREW	2	SM3/16" x 32 L = 4.5
34	23 - 0134	BED SLIDE SPRING	1	
35	23 - 0135	SCREW	2	SM11/64" x 40 L = 5
36	23 - 0163	BED SUPPORT PLATE	1	
37	23 - 0172	SCREW	2	SM15/64" x 28 L = 12
38	23 - 0144	THROAT PLATE PIN	1	
39	23 - 0162	BED SCREW STUD	2	SM15/64" x 28 L = 10
40	23 - 0139	SAFETY LABEL	1	
41	23 - 0121	SCREW	1	SM9/64" x 40 L = 6
42	23 - 0157	RUBBER PLUG	1	
43	23 - 0158	RUBBER PLUG	1	
44	23 - 0175	RUBBER PLUG	2	
45	23 - 0145	RUBBER PLUG	1	
46	23 - 0146	RUBBER PLUG	2	
47	23 - 0148	RUBBER PLUG	2	
48	23 - 0164	RUBBER PLUG	1	
49	23 - 0159	RUBBER PLUG	1	

## 2. UPPER SHAFT, LOWER SHAFT DRIVING & BALANCE COMPONENTS




## 2. UPPER SHAFT, LOWER SHAFT DRIVING & BALANCE COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 0201	UPPER SHAFT	1	
2	23 - 0202	UPPER SHAFT FRONT METAL	1	
3	24 - 0203	THREAD TAKE - UP LEVER	1	
4	24 - 0204	TAKE - UP LEVER	1	
5	24 - 0205	TAKE - UP LEVER THRUST PIN	1	
6	23 - 0206	SCREW	6	SM15/64" x 28 L = 8
7	24 - 0207	NEEDLE BAR CRANK ROD	1	
8	23 - 0208	OIL WICK	1	
9	23 - 0209	OIL WICK	1	
10	24 - 0210	NEEDLE BAR CRANK PIN	1	
11	23 - 0211	OIL WICK	1	
12	24 - 0212	COUNTERWEIGHT	1	
13	23 - 0261	FLYWHEEL	1	
14	23 - 0214	SCREW	2	M8 x 8
15	23 - 0215	UPPER FEED CAM	1	
16	23 - 0216	SCREW	4	SM1/4" x 40 L = 8
17	23 - 0217	UPPER SHAFT INNER METAL	1	
18	23 - 0218	OIL WICK	1	
19	23 - 0257	SCREW	2	SM11/64" x 40 L = 7
20	23 - 0220	ECCENTRIC CAM A	1	
21	23 - 0221	HORIZONTAL FEED CAM COVER	1	
22	23 - 0222	SAFETY CLUTCH DISC	1	
23	23 - 0223	UPPER SPROCKET	1	
24	23 - 0224	SCREW	2	SM1/4" x 40 L = 11
25	23 - 0225	TIMING BELT	1	
26	23 - 0226	BUSHING, REAR	1	
27	23 - 0227	UPPER SHAFT BEARING HOOK	1	
28	23 - 0228	SCREW	2	M6 x 6
29	23 - 0259	SCREW	2	SM15/64" x 28 L = 15
30	23 - 0258	BALANCER	1	
31	23 - 0231	LOWER SPROCKET	1	
32	23 - 0232	SPROCKET RING	1	
33	23 - 0233	SAFETY CLUTCH SPRING	1	
34	23 - 0234	SAFETY CLUTCH HOOK	1	
35	23 - 0235	SAFETY CLUTCH COUNTER - HOOK	1	
36	23 - 0236	COUNTER - HOOK SPRING	1	
37	23 - 0237	SAFETY CLUTCH SMALL LINK	1	
38	23 - 0238	SAFETY BASE	1	
39	23 - 0239	SAFETY CLUTCH SMALL LINK PIN	1	
40	23 - 0408	SCREW	2	SM1/4" x 40 L = 6
41	23 - 0241	HINGE SCREW	2	SM3/16" x 32 Φ6.35 H = 3.2
42	23 - 0243	SCREW	1	SM11/64" x 40 L = 9.5
43	23 - 0244	SAFETY CLUTCH PUSH BUTTON	1	
44	23 - 0255	SCREW	2	SM3/16" x 28 L = 8
45	23 - 0252	THRUST COLLAR, B	1	
46	23 - 0246	E - RING	1	
47	23 - 0247	SPRING	1	
48	23 - 0248	SAFETY CLUTCH KNOB SLEEVE	1	
49	23 - 0249	SCREW	2	SM15/64" x 28 L = 7
50	23 - 0254	BEARING	1	
514	23 - 0252	SCREW	1	



### 3. NEEDLE BAR ROCKING COMPONENTS




### 3. NEEDLE BAR ROCKING COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 0301	NEEDLE BAR FRAME	1	
2	23 - 0302	HINGE STUD	1	
3	23 - 0303	FELT	1	
4	23 - 0304	OIL WICK RETAINER	1	
5	23 - 0305	SCREW	1	SM15/64" x 28 L = 10.5
6	23 - 0106	FELT	1	
7	23 - 0307	NEEDLE BAR	1	
8	23 - 0308	NEEDLE ROD HOLDER	1	
9	23 - 0309	SCREW	1	SM9/64" x 40 L = 8
10	23 - 0310	FELT	1	
11	23 - 0311	NEEDLE CLAMP	1	
12	23 - 0312	SCREW	2	SM9/64" x 40 L = 3.5
13		NEEDLE	2	SY3355 160
14	23 - 0314	UPPER FEED BAR GUIDE	1	
15	23 - 0315	SCREW	2	SM11/64" x 40 L = 8
16	23 - 0316	ROCKING BASE GUIDE	1	
17	23 - 0317	SCREW	2	SM11/64" x 40 L = 7.5
18	23 - 0318	ROCKING BASE GUIDE (B)	1	
19	23 - 0319	SCREW	2	SM9/64" x 40 L = 10
20	23 - 0320	NEEDLE BAR ROCKING FRONTARM	1	
21	23 - 0321	SCREW	2	M8 x 8
22	23 - 0322	ROCKING SHAFT	1	
23	23 - 0323	SQUARE BLOCK	1	
24	23 - 0324	STUD	1	
25	23 - 0325	ROCKING SHAFT FRONT METAL	1	
26	23 - 0326	ROCKING SHAFT REAR METAL	1	
27	23 - 0327	ROCKING REAR ARM ASM.	1	
28	23 - 0328	ROCKING REAR ARM	1	
29	23 - 0329	SCREW	1	SM15/64" x 28 L = 24
30	23 - 0330	ROCKING REAR ARM FELT	1	
31	23 - 0331	CABLE BAND	1	



# 4. PRESSURE ADJUSTING & UPPER FEED MECHANISM COMPONENTS




#### 4. PRESSURE ADJUSTING & UPPER FEED MECHANISM COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 0401	UPPER FEED SHAFT	1	
2	23 - 0402	UPPER FEED FRONT ARM	1	
3	23 - 0403	SCREW	2	SM1/4" x 40 L = 6
4	23 - 0404	FRONT METAL	1	
5	23 - 0405	FEED SHAFT METAL	1	
6	24 - 0473	UPPER FEED STOPPER PLATE	1	
7	23 - 0407	MAIN SHAFT THRUST COLLAR	1	
8	23 - 0408	SCREW	2	SM1/4" x 40 L = 6
9	23 - 0249	SCREW	1	SM15/64" x 28 L = 7
10	23 - 0148	RUBBER PLUG	1	
11	23 - 0411	SCREW	1	SM15/64" x 28 L = 7
12	23 - 0412	UPPER FEED LINK	1	
13	23 - 0413	FELT	1	
14	23 - 0414	CLIP	1	
15	23 - 0415	HINGE SCREW, B	2	
16	23 - 0416	HINGE SCREW	1	
17	23 - 0417	SLIDE BLOCK	2	
18	23 - 0418	WASHER	1	
19	24 - 0419	TRIANGULAR LEVER	1	
20	23 - 0420	SCREW	1	SM11/64" x 40 L = 5
21	24 - 0498	PRESSER BAR LOWER BUSHING	1	
22	23 - 0422	FELT	1	
23	23 - 0423	WALKING BAR DRIVING LINK	1	
24	23 - 0424	WALKING BAR	1	
25	24 - 0425	UPPER FEED SPRING HOLDER	1	
26	23 - 0426	WALKING BAR SPRING	1	
27	23 - 0427	SCREW	1	SM15/64" x 28 L = 17
28	24 - 0428	UPPER FEED GUIDE PLATE	1	
29	23 - 0429	ROLLER	1	
30	23 - 0430	SCREW	2	SM15/64" x 28 L = 19
31	23 - 0431	UPPER FEED ROB	1	
32	23 - 0432	HINGE SCREW	1	
33	23 - 0433	CONNECTING STUD	1	
34	23 - 0434	WASHER	1	
35	23 - 0435	NUT	1	SM11/64" x 40
36	23 - 0436	UPPER FEED REAR ARM	1	
37	23 - 0437	SCREW	1	M6 x 22
38	23 - 0455	PRESSER FOOT ASM.	1	
39	23 - 0439	PRESSER BAR	1	
40	23 - 0315	SCREW	2	SM11/64" x 40 L = 7.5
41	23 - 0441	PRESSER BAR HOLDER	1	
42	23 - 0315	SCREW	1	SM11/64" x 40 L = 8
43	23 - 0443	NUT	1	
44	23 - 0444	PRESSER SPRING	1	
45	23 - 0445	HINGE SCREW	1	
46	23 - 0446	THREAD RELEASE HOLDING PLATE	1	
47	23 - 0447	THREAD RELEASE SPRING	1	
48	23 - 0448	PRESSER LIFTER LEVER	1	
49	23 - 0449	LINK SHAFT	1	
50	23 - 0450	SCREW	1	SM9/64" x 40 L = 9
51	23 - 0497	PRESSER ADJUSTING SCREW	1	
52	23 - 0451	WALKING FOOT	1	
53	23 - 0453	SCREW	1	SM11/64" x 40 L = 6.5




## 5. FEED MECHANISM COMPONENTS



## 5. FEED MECHANISM COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23-0566	SCREW	1	SM1/8" x 44 L = 18
2	24-0602	FEED BASE	1	
3	23-0503	FEED BASE FORK	1	
4	23-0504	SCREW	1	SM15/64" x 28 L = 14
5	23-0505	WASHER	1	
6	23-0506	SCREW	1	M5 x 5
7	23-0507	FEED BASE SHAFT	1	
8	23-0508	SNAP RING	1	
9	23-0509	OIL WICK	1	
10	23-0510	FEED ROCKER	1	
11	23-0511	SCREW	2	SM11/64" x 40 L = 14
12	23-0512	FEED ROCK SHAFT	1	
13	23-0513A,B	FEED ROCK SHAFT METAL	各 1	
14	23-0305	SCREW	1	SM15/64" x 28 L = 10.5
15	23-0515	FEED ROCKER SHAFT CRANK	1	
16	23-0516	SCREW	1	SM3/16" x 28 L = 15.5
17	23-0565	NUT	1	SM3/16" x 28
18	23-0407	MAIN SHAFT THRUST COLLAR	2	
19	23-0408	SCREW	6	SM1/4" x 40 L = 6
20	23-0520	NEEDLE BAR FRAME ROD	1	
21	23-0521	HINGE SCREW	2	SM9/32" x 28
22	23-0522	NUT	2	SM9/32" x 28
23	23-0523	FEED ADJUSTING BASE	1	
24	23-0524	FEED ADJUSTING BASE COVER	2	
25	23-0315	SCREW	4	SM11/64" x 40 L = 8
26	23-0526	SQUARE BLOCK	2	
27	23-0527	FEED ADJUSTING BASE SUPPORT	2	
28	23-0206	SCREW	2	SM15/64" x 28 L = 8
29	23-0529	FELT SUPPORT	1	
30	23-0530	SCREW	2	SM9/64" x 40 L = 6
31	23-0531	ECCENTRIC PIN	1	
32	23-0532	SCREW	2	SM9/64" x 40 L = 8.5
33	23-0533	FEED ADJUSTING ROD	1	
34	23-0534	HINGE SCREW	1	
35	23-0535	SPRING	1	
36	23-0536	SPRING HOOK	1	
37	23-0537	SCREW	2	SM11/64" x 40 L = 16
38	23-0538	FEED ADJUSTING A	1	
39	23-0539	FEED DRIVING SLIDE BLOCK	1	
40	23-0540	SCREW	1	M6 x 18
41	23-0541	FEED DIAL A	1	
42	23-0542	FEED DOG	1	
43	23-0543	SCREW	1	SM3/16" x 28 L = 18
44	23-0544	FEED REGULATOR SCREW	1	
45	23-0545	RUBBER RING	1	
46	23-0546	PIN	1	
47	23-0547	SPRING	1	
48	23-0563	SCREW	2	SM3/16" x 28 L = 9
49	23-0549	FEED LINK	1	
50	23-0550	CONNECTING FORKED LINK PIN	1	
51	23-0551	OIL WICK	1	
52	23-0552	SCREW	1	M5 x 6
53	23-0553	FEED ROD A	1	
54	23-0554	FEED LINK PIN	1	
55	23-0555	HINGE SCREW	1	
56	23-0556	BACKWARD FEED LEVER SHAFT	1	
57	23-0557	SCREW	2	SM1/8" x 40 L = 7
58	23-0564	FELT	1	
59	23-0559	THRUST COLLAR	1	
60	23-0562	REVERSE FEED CONTROL LEVER	1	
61	23-0561	E - RING	1	

# 6. HOOK SHAFT & LOWER SHAFT COMPONENTS






## 6. HOOK SHAFT & LOWER SHAFT COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 0655	SCREW	4	SM11/64" x 40 L = 4
2	23 - 0642	FEED DRIVING CAM	1	
3	23 - 0603	HOOK SHAFT BASE (RIGHT)	1	
4	23 - 0604	HOOK SHAFT BASE (LEFT)	1	
5	23 - 0546	SCREW	6	SM1/4" x 40 L = 6.2
6	23 - 0606	BOBBIN CASE OPENING LEVER LINK	2	
7	23 - 0607	CRANK SCREW STUD	2	
8	23 - 0608	OIL WICK	2	
9	23 - 0609	NUT	4	SM11/64" x 40
10	23 - 0648	HOOK DRIVING SHAFT GEAR, LARGE	2	
11	23 - 0611	BOBBIN CASE OPENING LEVER CRAN	2	
12	23 - 0216	SCREW	4	SM1/4" x 40 L = 8
13	23 - 0613	OPENING LEVER CRANK PIN	2	
14	23 - 0614	SCREW	2	SM11/64" x 40 L = 18
15	23 - 0615	OIL WICK	2	
16	23 - 0644	SCREW	3	SM1/4" x 40 L = 4.5
17	23 - 0617	BOBBIN CASE OPENING LEVER	2	
18	23 - 0618	WASHER	2	
19	23 - 0619	SCREW	2	SM9/64" x 40 L = 7.5
20	23 - 06* *	WASHER	2	
21	23 - 0652	OIL PUMP SHAFT	1	
22	23 - 0645	HOOK DRIVING SHAFT GEAR, SMALL	2	
23	23 - 0623	HOOK SHAFT UPPER METAL	2	
24	23 - 0624	HOOK SHAFT LOWER METAL	2	
25	23 - 0625	SADDLE INSTALLING BLOCK, UPPER	2	
26	23 - 0626	SADDLE INSTALLING BLOCK, LOWER	2	
27	23 - 0627	SCREW	2	SM15/64" x 28 L = 30
28	23 - 0628	WASHER	2	
29	23 - 0629	SCREW	2	M8 x 25
30	23 - 0630	OIL ADJUSTING SCREW	2	
31	23 - 0640	BUSHING ASM., INTERMEDIATE	1	
32	23 - 1539	CONNECTING SCREW	4	
33		VERTICAL HOOK ASM.	2	
34	23 - 0654	PLUNGER BUSHING, B	1	
35	23 - 0635	BOBBIN	2	
36	23 - 0636	LOWER SHAFT (2 - NEEDLE)	1	
37	23 - 0637	BUSHING ASM, FRONT	1	
38	23 - 0305	SCREW	2	SM15/64" x 28 L = 10.5

# 7. THREAD TENSION COMPONENTS




## 7. THREAD TENSION COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 0901	THREAD TENSION ASM.	1	
2	23 - 0902	THREAD TAKE - UP SPRING, A	1	
3	23 - 0903	THREAD TAKE - UP SPRING STUD	1	
4	23 - 0904	TENSION BASE PLATE ASM.	1	
5	23 - 0905	TENSION RELEASE LEVER	1	
6	23 - 0906	HINGE SCREW	2	
7	23 - 0907	PIN B	1	
8	23 - 0908	TENSION RELEASE PIN, SHORT	1	
9	23 - 0909	NUT	2	SM11/64" x 40
10	23 - 0910	THREAD TENSION POST, A	1	
11	23 - 0911	BOBBIN WINDER TENSION DISC	4	
12	23 - 0912	TENSION SPRING NO. 1	2	
13	23 - 0913	THREAD TENSION NUT	2	
14	23 - 0914	THREAD TENSION POST, B	1	
15	23 - 0915	TENSION DISC	4	
16	23 - 0916	TENSION DISC HOLDER	2	
17	23 - 0917	TENSION SPRING	2	
18	23 - 0918	ROTATING STOPPER	2	
19	23 - 0919	TENSION NUT	2	
20	23 - 0920	TAKE - UP SPRING GUIDE STUD	1	
21	23 - 0921	TAKE - UP SPRING GUIDE ASM.	2	
22	23 - 0922	TAKE - UP SPRING GUIDE PLATE	1	
23	23 - 0923	COLLAR	1	
24	23 - 0924	THREAD TAKE - UP SPRING B	1	
25	23 - 0925	THREAD TENSION POST	1	
26	23 - 0926	SCREW	1	SM1/8" x 44 L = 3.5
27	23 - 0927	SCREW	1	SM1/8" x 44 L = 5.5
28	23 - 0928	ADJUSTING PLATE B	1	
29	23 - 0933	SCREW	1	SM9/64" x 40 L = 4.5
30	23 - 0930	PRESSER COLLAR	1	
31	23 - 0931	TAKE - UP SPRING GUIDE	1	
32	23 - 0932	THREAD TENSION NUT	1	
33	23 - 0915	SCREW	2	SM11/64" x 40 L = 8.5
34	23 - 0935	TENSION RELEASE BAR	1	
35	23 - 0937	SPRING PIN	1	





# 8. KNEE LIFTING COMPONENTS



## 8. KNEE LIFTING COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 1101	KNEE LIFTER SHAFT BASIS	1	
2	23 - 1102	SCREW	3	M6 x 12
3	23 - 1103	KNEE LIFTER SHAFT A ASM.	1	
4	23 - 1104	KNEE LIFTER SHAFT A	1	
5	23 - 1105	KNEE LIFTER SHAFT PIN	1	
6	23 - 1106	KNEE LIFTER SHAFT A SPRING	1	
7	23 - 1107	KNEE LIFTER SPRING RACK	1	
8	23 - 1108	SCREW M5 x 0.8 L = 16	4	M5 x 16
9	23 - 1109	KNEE LIFTER SHAFT B	1	
10	23 - 1110	E - SHAPED SNAP RING	1	
11	23 - 1111	KNEE LIFTER LEVER B	2	
12	23 - 1137	SCREW	1	
13	23 - 1113	KNEE LIFTER LEVER A	1	
14	23 - 1138	KNEE LIFTER LEVER STAY	1	
15	23 - 1115	SCREW	1	M5 x 25
16	23 - 1116	NUT	1	M5
17	23 - 1117	KNEE LIFTER LINK	1	
18	23 - 1120	HINGE SCREW	4	
19	23 - 1119	KNEE LIFTER CONNECTING PLATE	1	
20	20 - 0721	KNEE PAD PLATE SUPPORT	1	
21	23 - 1121	KNEE LIFTER LEVER	1	
22	23 - 1122	SCREW	2	SM9/64" x 40 L = 25
23	23 - 1123	KNEE LIFTER JOINT ASM.	1	
24	23 - 1124	KNEE LIFTER JOINT	1	
25	23 - 1125	PRESSER SPRING	1	
26	23 - 1126	SCREW	1	SM9/64" x 40 L = 4.7
27	23 - 1127	FITTING ARM ASM. (VERTICAL)	1	
28	23 - 1128	BRACKET	1	
29	20 - 0711	SCREW	2	M6 x 24
30	20 - 0716	KNEE PRESS PLATE ASM.	1	
31	20 - 0722	SCREW	1	M6 x 12
32	20 - 0718	KNEE PRESS LEVER		
33	20 - 0717	KNEE PAD PLATE COVER	1	
34	20 - 0719	KNEE PAD PLATE RUBBER	1	
35	20 - 0720	KNEE PAD PLATE	1	

# 9. LOWER THREAD WINDER MECHANISM COMPONENTS






## 9. LOWER THREAD WINDER MECHANISM COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 1201	BOBBIN DEVICE ASM.	1	
2	23 - 1202	BOBBIN FITTING BASIS COMPL.	1	
3	23 - 1203	BOBBIN SHAFT COMPL.	1	
4	23 - 1204	BOBBIN CAMSHAFT COMPL.	1	
5	23 - 1205	BOBBIN LEVER	1	
6	23 - 1206	ADJUSTING PLATE	1	
7	23 - 1207	PRESSUR FOOT SPRING	1	
8	23 - 1208	VERTICAL ROLLER WASHER	1	
9	23 - 1209	RUBBER RING	1	
10	23 - 1210	CUSHION	1	
11	23 - 1211	SPRING	1	
12	23 - 1212	RETAINING RING	1	
13	23 - 1213	E - RING	1	
14	23 - 1214	RUBBER RING	1	
15	23 - 1215	SCREW	1	SM9/64" x 40 L = 13.5
16	23 - 1216	SCREW	1	SM9/64" x 40 L = 5
17	23 - 1217	BOBBIN ADJUSTING PLATE	1	
18	23 - 1218	SCREW	3	SM11/64" x 40 L = 8
19	23 - 1219	BOBBIN FRICTION WHEEL	1	
20	23 - 1220	SCREW	2	M5 x 6
21	23 - 1221	THREAD CUTTER	1	
22	23 - 1222	SCREW	2	SM9/64" x 40 L = 6
23	23 - 1223	LOWER THREAD GUIDE ASM.	1	
24	23 - 1224	FITTING BASE	1	
25	23 - 1225	THREAD GUIDE	1	
26	23 - 1226	NUT	1	SM11/64" x 40
27	23 - 1227	TENSION SPRING NO. 1	1	
28	23 - 1228	BOBBIN WINDER TENSION DISC	2	
29	23 - 1229	THREAD TENSION POST, A	1	
30	23 - 1230	THREAD TENSION NUT	1	
31	23 - 1231	SCREW	2	SM3/16" x 32 L = 9
32	23 - 1232	TACKING	1	

# 10. LUBRICATION COMPONENTS




# 10. LUBRICATION COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 1501	ARM ONCE THROUGH OIL FELT ASM.	1	
2	23 - 1502	ARM ONCE THROUGH FELT A	1	
3	23 - 1503	FELT B	1	
4	23 - 1504	FACE ONCE THROUGH FELT	1	
5	23 - 1505	FELT SUPPORT ASM.	1	
6	23 - 1506	FELT	1	
7	23 - 1507	FEED CHANGE FELT	1	
8	23 - 1508	FELT	1	
9	23 - 0414	CLIP CV - 70S	3	
10	23 - 1510	SCREW	1	SM11/64" x 40 L = 4.3
11	23 - 1511	UPPER FEED OIL BAR PLATE	1	
12	23 - 1512	SCREW	1	SM11/64" x 40 L = 5
13	23 - 1513	OIL WICK	1	
14	23 - 1514	TAKE - UP OIL PLATE	1	
15	23 - 1515	OIL WICK	1	
16	23 - 1516	TAKE - UP LIBRICATION FELT	1	
17	23 - 1517	SCREW	1	SM9/64" x 40 L = 6
18	23 - 1518	FELT	1	
19	23 - 1519	FELT	1	
20	23 - 1520	OIL TUBE	1	
21	23 - 1521	OIL RETURN TUBE HOLDER	2	
22	23 - 1541	SCREW	2	SM11/64" x 40 L = 6
23	23 - 1523	ARM OIL TANK ASM.	1	
24	23 - 1524	OIL SIGHT WINDOW	1	
25	23 - 1525	ARM OIL TANK	1	
26	23 - 1566	CLIP BAND	1	
27	23 - 1554	TUBE	1	
28	23 - 1528	SCREW	2	SM11/64" x 40 L = 9.5
29	23 - 1562	WASHER	1	
30	23 - 1561	OIL WICK HOLDER	1	
31	23 - 1559	OIL TUBE HOLDER	1	
32	23 - 1532	PIPE SUPPORT	1	
33	23 - 0317	SCREW	1	SM11/64" x 40 L = 7.5
34	23 - 1534	LUBRICATION BRACKET	1	
35	23 - 1535	SCREW	4	SM15/64" x 28 L = 9
36	23 - 1536	OIL PIPE STAY	1	
37	23 - 1563	TUBE	1	
38	23 - 1538	CONNECTING SCREW	2	
39	23 - 1539	CONNECTING SCREW	3	
40	23 - 1553	TUBE	1	
41	23 - 1565	CABLE BAND	1	
42	23 - 1542	OIL CONNECT ARM	1	
43	23 - 1543	PLUNGER	1	
44	23 - 1544	PLUNGER SPRING	1	
45	23 - 1545	PLUNGER THRUST PLATE	1	
46	23 - 0105	SCREW	1	SM11/64" x 40 L = 8
47	23 - 1564	SCREW	1	M4 x 7.3
48	23 - 1548	TUBE	1	
49	23 - 1549	TUBE	1	
50	23 - 1550	TUBE	1	
51	23 - 1551	TUBE	1	
52	23 - 1552	TUBE	1	
53	23 - 1553	OIL WICK	1	
54	23 - 1546	OIL WICK	1	
55	23 - 1560	OIL WICK	1	



# 11. ACCESSORIES PARTS COMPONENTS



## 11. ACCESSORIES PARTS COMPONENTS

REF	PART NO.	PART NAME	Qty	DESCRIPTION
1	23 - 2001	OIL RESERVOIR	1	
2	23 - 2002	SCREW	1	SM15/64" x 28 L = 14
3	23 - 2003	SCREW	1	SM11/64" x 40 L = 7.8
4	23 - 2004	SCREW	1	SM11/64" x 40 L = 6.5
5	23 - 2005	OIL MANAGEMENT	1	
6	23 - 2006	WASHER	1	
7	23 - 2007	OIL SEAL	1	
8	23 - 2008	OIL CAN	1	
9	23 - 2009	SCREW	4	M3 x 14
10	23 - 2010	NUT	4	M3
11	23 - 2011	OIL REMOVING SETSCREW PACKING	8	
12	23 - 2012	WASHER	4	
13	23 - 2013	CUSHION SET NAIL	10	
14	23 - 2310	FELT CUSHION	4	
15	23 - 2015	BELT COVER C(JE)	1	
16	23 - 2016	WOOD SCREW	2	
17	23 - 2311	RUBBER CUSHION	4	
18	23 - 2018	BELT COVER (RIGHT)	1	
19	23 - 2019	BELT COVER AUXILIARY PLATE	1	
20	23 - 2020	BELT COVER (LEFT)	1	
21	23 - 2021	BELT COVER SUPPORT A	1	
22	23 - 2022	SCREW	2	SM15/64" x 28 L = 30
23	23 - 2023	OIL TANK ASM.	1	
24	23 - 2024	FILTER	1	
25	23 - 2025	FILTER CAP	1	
26	23 - 2026	FILTER PLATE	1	
27	23 - 2027	OIL TANK	1	
28	23 - 2028	COVER (LOWER)	1	
29	23 - 2029	SCREW	3	M2 x 10
30	23 - 2030	WING NUT	1	
31	23 - 2031	RUBBER PLUG	1	
32	23 - 2032	FILTER	1	
33	23 - 2033	COVER REAR	1	
34	23 - 2034	FILTER CASE	1	
35	23 - 2035	OIL RESERVOIR MAGNET	1	
36	23 - 2036	FILTER PACKING	1	
37	5 - 0912	COVER	1	
38	5 - 0901	ACCESSORY BOX	1	
39	5 - 0903	SCREW DRIVER	1	3.4 x 70
40	23 - 2303	WRENCH	1	9 x 10
41	23 - 2312	RUBBER SPACER	2	
42	23 - 2321	SPACER	2	
43	23 - 2318	WRENCH	1	3/32
44	23 - 2320	CUSHION	4	
45	23 - 2304	NEW DEFRIX OIL	1	
46	23 - 2305	OILER	1	
47	5 - 0914	HINGE	2	
48		NEEDLE	4	SY3355 160
49	23 - 0635	BOBBIN	4	
50	10 - 1009	THREAD STANDING DEVICE ASM.	1	