


## Model: PBS & PBT Parts List




NC Carpet Binding & Equipment Corp.  
858 Summer Avenue  
Newark, NJ 07104


USA: 973-481-3500 Email: [sales@nccarpet.com](mailto:sales@nccarpet.com)  
Fax: 1-973-481-0839 Canada: 1-800-336-1184




| Part No. | Name of parts           | Qty | Part No. | Name of parts        | Qty |
|----------|-------------------------|-----|----------|----------------------|-----|
| 49-1     | Face plate              | 1   | 163      | Set screw for 161-1  | 3   |
| 50       | Face plate hinge pin    | 1   | 182-1    | Oil pin              | 3   |
| 51       | Face plate hinge        | 1   | 204      | Front plate          | 1   |
| 52       | Set screw for 51        | 1   | 420      | Tape guide A asm.    | 1   |
| 76       | Tension dial assembly   | 1   | 421      | Tape guide B asm.    | 1   |
| 77       | Set screw for 76        | 1   | 422      | Tape holder          | 1   |
| 78       | Face plate thread guide | 1   | 423      | Tape holder shaft    | 1   |
| 79       | Set screw for 78        | 2   | 426      | Carrying handle      | 1   |
| 80       | Arm thread guide        | 1   | 446      | Set screw for 421    | 1   |
| 81       | Set screw for 80        | 1   | 448-1    | Set screw for 426    | 2   |
| 82       | Spring washer for 81    | 1   | 461      | Set screw for 420    | 1   |
| 83       | Washer for 81           | 1   | 470      | Washer for 420       | 1   |
| 151-1    | Top plate               | 1   | 476      | Caution note label B | 1   |
| 152      | Set screw for 151-1     | 2   | 507A     | Thread guide tube    | 1   |
| 153      | Top plate thread guide  | 1   | 525A-1   | Spool holder asm.    | 1   |
| 154      | Set screw for 153       | 1   | 601      | Washer for 151-1     | 2   |
| 161-1    | Belt cover              | 1   | 602      | Set screw for 525A-1 | 1   |




| Part No. | Name of parts                | Qty | Part No. | Name of parts           | Qty |
|----------|------------------------------|-----|----------|-------------------------|-----|
| 1        | Needle bar driving frame     | 1   | 30       | Take-up lever crank     | 1   |
| 2        | Needle bar driving frame pin | 1   | 31       | Set screw for 30        | 1   |
| 3        | Snap ring for 2              | 1   | 32       | Arm shaft crank         | 1   |
| 4        | Collar for 2                 | 1   | 33       | Set screw(A) for 32     | 1   |
| 5        | Set screw for 4              | 1   | 34       | Spring pin for 32       | 1   |
| 6        | Set screw for 2              | 1   | 35       | Set screw(B) for 32     | 1   |
| 7        | Zigzag driving crank spring  | 1   | 36       | Arm shaft front bushing | 1   |
| 8        | Adjusting screw for 1        | 1   | 37       | Set screw for 36        | 1   |
| 10       | Set screw for 8              | 1   | 38       | Arm shaft collar        | 1   |
| 13       | Needle 435 #22               | 1   | 39       | Set screw for 38        | 2   |
| 26       | Needle bar connecting link   | 1   | 412      | Needle bar              | 1   |
| 27       | Needle bar connection stud   | 1   | 456      | Set screw for 412       | 1   |
| 28       | Take-up lever                | 1   | 603      | Shim washer             | 1   |
| 29       | Set screw for 28             | 1   |          |                         |     |




| Part No. | Name of parts           | Qty | Part No. | Name of parts               | Qty |
|----------|-------------------------|-----|----------|-----------------------------|-----|
| 40       | Worm gear               | 1   | 61       | Crank rod                   | 1   |
| 41       | Set screw for 40        | 2   | 62       | Crank rod hinge screw w/nut | 1   |
| 42A      | feed cum                | 1   | 63A      | Forled rod                  | 1   |
| 43       | Set screw for 42A       | 1   | 65       | Feed regulator slide block  | 1   |
| 44-1     | Arm shaft back bushing  | 1   | 150-1    | Zigzag driving crank        | 1   |
| 45       | Hand wheel bushing      | 1   | 177      | Zigzag driving crank guide  | 1   |
| 46       | Set screw for 45        | 1   | 201-1    | Unit frame assembly         | 1   |
| 47       | Spring pin for 45       | 1   | 203      | Set screw for 201-1         | 3   |
| 48-1     | Arm shaft               | 1   | 436      | V-belt                      | 1   |
| 54       | Hand wheel              | 1   | 459      | Set screw for 54            | 2   |
| 55       | Stop motion screw       | 1   | 519      | Feed driving eccentric cam  | 1   |
| 56       | Stop motion clamp screw | 1   | 544      | Set screw for 519           | 1   |
| 57       | Stop motion washer      | 1   |          |                             |     |




| Part No. | Name of parts                    | Qty | Part No. | Name of parts              | Qty |
|----------|----------------------------------|-----|----------|----------------------------|-----|
| 14       | Presser regulator                | 1   | 518      | Hinge screw                | 1   |
| 20       | Presser bar spring bracket       | 1   | 532NS    | Set screw for 604          | 4   |
| 21       | Set screw for 20                 | 1   | 536NS    | Set screw for 512NS        | 1   |
| 22       | Presser foot lifter              | 1   | 542      | Set screw for 517-1        | 2   |
| 23       | Presser foot lifter hinge stud   | 1   | 543      | Set screw for 506          | 4   |
| 403      | Roller                           | 1   | 543-1    | Set screw for 563          | 3   |
| 404      | Roller bracket                   | 1   | 545      | Nut                        | 1   |
| 406      | Presser bar                      | 1   | 549-1    | Set screw for 515NS        | 2   |
| 442      | Presser spring                   | 1   | 557      | Washer for 512NS           | 1   |
| 449      | Set screw for 404                | 1   | 558      | Supporting screw for 512NS | 1   |
| 450      | Set screw for 403                | 2   | 560      | Joint pin                  | 1   |
| 505NS    | Connecting shaft                 | 1   | 561      | Washer for hinge screw 518 | 1   |
| 506      | Joint                            | 1   | 562      | Washer for hinge screw 518 | 1   |
| 510      | Roller shaft                     | 1   | 563      | Clutch shaft connector     | 1   |
| 512NS    | Clutch shaft                     | 1   | 604      | Clutch connecting crank    | 1   |
| 513NS    | Clutch                           | 1   | 605      | Clutch holder base         | 1   |
| 515NS    | Clutch holder asm.               | 1   | 606      | Set screw for 515NS        | 2   |
| 517-1    | feed driving shaftconnecting rod | 1   |          |                            |     |



| Part No. | Name of parts                  | Qty |  |  |  |  |
|----------|--------------------------------|-----|--|--|--|--|
| 64       | Forked rod hinge screw w/nut   | 1   |  |  |  |  |
| 128      | Feed rock shaft asm.           | 1   |  |  |  |  |
| 129      | Screw center w/nut for 128     | 2   |  |  |  |  |
| 131      | Set screw for 419              | 2   |  |  |  |  |
| 137      | Feed crank asm.                | 1   |  |  |  |  |
| 138      | Spring holder w/spring for 137 | 1   |  |  |  |  |
| 139      | Set screw for 137              | 1   |  |  |  |  |
| 140      | Set screw for 138              | 1   |  |  |  |  |
| 418      | Feed dog                       | 1   |  |  |  |  |
| 419      | Needle plate                   | 1   |  |  |  |  |
| 440      | Binder plate                   | 1   |  |  |  |  |
| 443      | Set screwfor 418               | 2   |  |  |  |  |
| 454      | Set screwfor 440               | 1   |  |  |  |  |
| 644      | Set screw for Attachment       | 1   |  |  |  |  |
| 645      | Set screw for Attachment       | 1   |  |  |  |  |
| 646      | Washer for Attachment          | 2   |  |  |  |  |




| Part No. | Name of parts                       | Qty | Part No. | Name of parts             | Qty |
|----------|-------------------------------------|-----|----------|---------------------------|-----|
| 101      | Shuttle race                        | 1   | 119      | Lower shaft               | 1   |
| 102      | Shuttle race retaining ring         | 1   | 120      | Lower shaft front bushing | 1   |
| 102S     | Race cap spring                     | 1   | 121      | Set screw for 120         | 2   |
| 103      | Set screw for 101                   | 1   | 122      | Lower shaft cam           | 1   |
| 105NS    | Shuttle driver shaft shuttle driver | 1   | 123      | Set screw for 122         | 1   |
| 106      | Shuttle driver shaft bushing        | 1   | 124      | Lower shaft back bushing  | 1   |
| 107      | Set screw for 106                   | 1   | 125      | Set screw for 124         | 1   |
| 108      | Shuttle driver shaft collar         | 1   | 126      | Lower shaft crank         | 1   |
| 109      | Set screw for 108                   | 2   | 127      | Set screw for 126         | 2   |
| 110      | Shuttle driver shaft bevel gear     | 1   | 130      | Shuttle cleaner           | 1   |
| 111      | Set screw (A) for 110               | 1   | 133      | Gear box cover            | 1   |
| 112      | Set screw (B) for 110               | 1   | 134      | Plastic packing           | 1   |
| 113      | Lower shaft bevel gear              | 1   | 135      | Set screw for 133         | 3   |
| 114      | Set screw (A) for 113               | 1   | 176      | Washer for 119            | 2   |
| 115      | Set screw (B) for 113               | 1   | 607      | Thrust collar             | 2   |
| 116      | Shuttle hook                        | 1   | 608      | Set screw for 608         | 4   |
| 117      | Bobbin case                         | 1   | 609      | Washer for 126            | 2   |
| 118      | Shuttle driving spring              | 1   |          |                           |     |



| Part No. | Name of parts                       | Qty | Part No. | Name of parts              | Qty |
|----------|-------------------------------------|-----|----------|----------------------------|-----|
| 166-1    | LED light asm.                      | 1   | 477      | Band                       | 5   |
| 167      | Set screw for 166-1                 | 2   | 478      | Closed-end connector       | 2   |
| 178-1    | Switch                              | 1   | 553      | Motor 115V 120W            | 1   |
| 427-1    | Switch handle                       | 1   | 610      | Set screw for 435-1        | 2   |
| 428-1    | Switch handle cover                 | 1   | 611      | Washer for 435-1           | 2   |
| 429NS    | Switch                              | 1   | 612      | Spring washer for 435-1    | 2   |
| 430      | Caster A                            | 1   | 613      | Set screw for 474NS        | 1   |
| 431-1    | Caster B                            | 1   | 614      | Closed-end connector       | 2   |
| 432NS    | Caster C                            | 1   | 615      | Cord clamp (nk-8n)         | 1   |
| 433      | Large gear asm. (in needle bearing) | 1   | 616      | Set screw for 615          | 1   |
| 434      | Small gear                          | 1   | 617      | Insulation sheet           | 1   |
| 435-1    | Motor bracket                       | 1   | 618      | Set screw for 427-1        | 4   |
| 437      | Large gear shaft                    | 1   | 619      | Screw(set)                 | 1   |
| 438NS    | Connector cable                     | 1   | 620      | Nut                        | 1   |
| 445      | Set screw for 428-1                 | 2   | 621      | Cord clamp (nk-6n)         | 1   |
| 451      | Set screw for 434                   | 1   | 622      | Set screw for 621          | 1   |
| 452      | Washer for 433                      | 1   | 623      | Power supply               | 1   |
| 453NS    | Set screw for 432NS                 | 2   | 624      | Power supply bracket       | 1   |
| 458      | Set screw for 429NS                 | 2   | 625      | Set screw for 624          | 2   |
| 467      | Nut for 433                         | 1   | 626      | Washer for 624             | 2   |
| 474NS    | Plate                               | 1   | 627      | Set screw for caster A & B | 2   |
| 475NS    | Bush                                | 1   | 628      | Washer for caster A & B    | 2   |




# ACCESSORIES




| Part No. | Name of parts              | Qty |  |  |  |  |
|----------|----------------------------|-----|--|--|--|--|
| 301      | Accessory box              | 1   |  |  |  |  |
| 302      | Screwdriver-small          | 1   |  |  |  |  |
| 303      | Screwdriver-large          | 1   |  |  |  |  |
| 305      | Needle ( 5 pieces)         | 1   |  |  |  |  |
| 306      | Tweezers                   | 1   |  |  |  |  |
| 308      | Hexagonal wrench ( 3mm )   | 1   |  |  |  |  |
| 309      | Hexagonal wrench ( 4mm )   | 1   |  |  |  |  |
| 310      | Hexagonal wrench ( 2mm )   | 1   |  |  |  |  |
| 629      | Oiler asm.                 | 1   |  |  |  |  |
| 630      | Spanner                    | 1   |  |  |  |  |
| 631      | Hexagonal wrench ( 2.5mm ) | 1   |  |  |  |  |

# EXCLUSIVE PARTS FOR MODEL PBT



| Part No. | Name of parts                  | Qty | Part No. | Name of parts        | Qty |
|----------|--------------------------------|-----|----------|----------------------|-----|
| 501      | Presser spring regulator screw | 1   | 530      | Face plate hinge pin | 1   |
| 502-1    | Top plate                      | 1   | 531      | Hand lifter B        | 1   |
| 503-1    | Face plate                     | 1   | 534      | Set screw for 527    | 1   |
| 508-1    | Roller base asm.               | 1   | 539-1    | Set screw for 508-1  | 2   |
| 511      | Presser bar                    | 1   | 552-1    | Oil pin for 502-1    | 3   |
| 521-1    | Lower roller plate             | 1   | 540      | Set screw for 526    | 1   |
| 522      | Lower roller                   | 1   | 541      | Set screw for 524    | 1   |
| 523      | Lower roller shaft             | 1   | 547      | Set screw for 521-1  | 2   |
| 524      | Presser lifter lever           | 1   | 632      | Washer for 508-1     | 1   |
| 526      | Presser bar guide bracket      | 1   | 633      | Dust cover           | 1   |
| 527      | Hand lifter pin                | 1   | 634      | Set screw for 633    | 1   |
| 528      | Presser spring                 | 1   |          |                      |     |



| Part No. | Name of parts           | Qty | Part No. | Name of parts              | Qty |
|----------|-------------------------|-----|----------|----------------------------|-----|
| 504      | Roller                  | 1   | 549-1    | Set screw for 637          | 2   |
| 505NS    | Connecting shaft        | 1   | 557      | Washer for 512NS           | 2   |
| 506      | Joint                   | 1   | 558      | Supporting screw for 512NS | 2   |
| 509-1    | Roller bracket          | 1   | 560      | Joint pin                  | 1   |
| 510      | Roller shaft            | 1   | 563      | Clutch shaft connector     | 1   |
| 512NS    | Clutch shaft            | 2   | 604      | Clutch connecting crank    | 1   |
| 513NS    | Clutch                  | 2   | 606      | Set screw for 515NS & 635  | 6   |
| 515NS    | Clutch holder asm.      | 1   | 635      | Clutch holder              | 1   |
| 516-1    | Clutch connecting crank | 1   | 636      | Set screw for 512NS        | 1   |
| 529-1    | Hand lifter A           | 1   | 637      | Clutch holder base         | 1   |
| 532NS    | Set screw for 516-1     | 8   | 638      | L-ball                     | 1   |
| 533-1    | Set screw for 509-1     | 2   | 639      | Nylon nut                  | 2   |
| 535      | Set screw for 504       | 2   | 640      | Rod                        | 1   |
| 536NS    | Set screw for 512NS     | 1   | 641      | Nut for 640                | 2   |
| 543      | Set screw for 506       | 4   | 642      | HINGE SCREW                | 1   |
| 543-1    | Set screw for 563       | 3   | 643      | BRACKET                    | 1   |

# NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

| <u>PART NO.</u> | <u>PAGE:</u> | <u>PART NO.</u> | <u>PAGE:</u> |
|-----------------|--------------|-----------------|--------------|
| 1               | PAGE 2       | 52              | PAGE 1       |
| 2               | PAGE 2       | 54              | PAGE 3       |
| 3               | PAGE 2       | 55              | PAGE 3       |
| 4               | PAGE 2       | 56              | PAGE 3       |
| 5               | PAGE 2       | 57              | PAGE 3       |
| 6               | PAGE 2       | 61              | PAGE 3       |
| 7               | PAGE 2       | 62              | PAGE 3       |
| 8               | PAGE 2       | 63A             | PAGE 3       |
| 10              | PAGE 2       | 64              | PAGE 5       |
| 13              | PAGE 2       | 65              | PAGE 3       |
| 14              | PAGE 4       | 76              | PAGE 1       |
| 20              | PAGE 4       | 77              | PAGE 1       |
| 21              | PAGE 4       | 78              | PAGE 1       |
| 22              | PAGE 4       | 79              | PAGE 1       |
| 23              | PAGE 4       | 80              | PAGE 1       |
| 26              | PAGE 2       | 81              | PAGE 1       |
| 27              | PAGE 2       | 82              | PAGE 1       |
| 28              | PAGE 2       | 83              | PAGE 1       |
| 29              | PAGE 2       | 101             | PAGE 6       |
| 30              | PAGE 2       | 102S            | PAGE 6       |
| 31              | PAGE 2       | 102             | PAGE 6       |
| 32              | PAGE 2       | 103             | PAGE 6       |
| 33              | PAGE 2       | 105NS           | PAGE 6       |
| 34              | PAGE 2       | 106             | PAGE 6       |
| 35              | PAGE 2       | 107             | PAGE 6       |
| 36              | PAGE 2       | 108             | PAGE 6       |
| 37              | PAGE 2       | 109             | PAGE 6       |
| 38              | PAGE 2       | 110             | PAGE 6       |
| 39              | PAGE 2       | 111             | PAGE 6       |
| 39              | PAGE 1       | 112             | PAGE 6       |
| 40              | PAGE 3       | 113             | PAGE 6       |
| 41              | PAGE 3       | 114             | PAGE 6       |
| 42A             | PAGE 3       | 115             | PAGE 6       |
| 43              | PAGE 3       | 116             | PAGE 6       |
| 44-1            | PAGE 3       | 116-1           | PAGE 7       |
| 45              | PAGE 3       | 117             | PAGE 6       |
| 46              | PAGE 3       | 118             | PAGE 6       |
| 47              | PAGE 3       | 119             | PAGE 6       |
| 48-1            | PAGE 3       | 120             | PAGE 6       |
| 49-1            | PAGE 2       | 121             | PAGE 6       |
| 50              | PAGE 2       | 122             | PAGE 6       |
| 51              | PAGE 1       | 123             | PAGE 6       |

# NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

| <u>PART NO.</u> | <u>PAGE:</u> | <u>PART NO.</u> | <u>PAGE:</u> |
|-----------------|--------------|-----------------|--------------|
| 124             | PAGE 6       | 418             | PAGE 5       |
| 125             | PAGE 6       | 419             | PAGE 5       |
| 126             | PAGE 6       | 420             | PAGE 2       |
| 127             | PAGE 6       | 421             | PAGE 1       |
| 128             | PAGE 5       | 422             | PAGE 1       |
| 129             | PAGE 5       | 423             | PAGE 1       |
| 130             | PAGE 6       | 426             | PAGE 1       |
| 131             | PAGE 5       | 427-1           | PAGE 7       |
| 133             | PAGE 6       | 428             | PAGE 7       |
| 134             | PAGE 6       | 429NS           | PAGE 7       |
| 135             | PAGE 6       | 430             | PAGE 7       |
| 137             | PAGE 5       | 431-1           | PAGE 7       |
| 138             | PAGE 5       | 432NS           | PAGE 7       |
| 139             | PAGE 5       | 433             | PAGE 7       |
| 140             | PAGE 5       | 434             | PAGE 7       |
| 150-1           | PAGE 3       | 435-1           | PAGE 7       |
| 151-1           | PAGE 2       | 436             | PAGE 3       |
| 152             | PAGE 1       | 437             | PAGE 7       |
| 153             | PAGE 1       | 438NS           | PAGE 7       |
| 154             | PAGE 1       | 440             | PAGE 5       |
| 161-1           | PAGE 1       | 442             | PAGE 4       |
| 163             | PAGE 1       | 443             | PAGE 5       |
| 167             | PAGE 7       | 445             | PAGE 7       |
| 176             | PAGE 6       | 446             | PAGE 1       |
| 177             | PAGE 3       | 448-1           | PAGE 1       |
| 178-1           | PAGE 7       | 449             | PAGE 4       |
| 182-1           | PAGE 1       | 450             | PAGE 4       |
| 201-1           | PAGE 3       | 451             | PAGE 7       |
| 203             | PAGE 3       | 452             | PAGE 7       |
| 204             | PAGE 1       | 453NS           | PAGE 7       |
| 301             | PAGE 8       | 454             | PAGE 5       |
| 302             | PAGE 8       | 456             | PAGE 1       |
| 303             | PAGE 8       | 458             | PAGE 7       |
| 305             | PAGE 8       | 459             | PAGE 3       |
| 306             | PAGE 8       | 461             | PAGE 2       |
| 308             | PAGE 8       | 467             | PAGE 7       |
| 309             | PAGE 8       | 470             | PAGE 1       |
| 310             | PAGE 8       | 474NS           | PAGE 7       |
| 403             | PAGE 4       | 475NS           | PAGE 7       |
| 404             | PAGE 4       | 476             | PAGE 1       |
| 406             | PAGE 4       | 477             | PAGE 7       |
| 412             | PAGE 1       | 478             | PAGE 7       |

# NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

| <u>PART NO.</u> | <u>PAGE:</u> | <u>PART NO.</u> | <u>PAGE:</u> |
|-----------------|--------------|-----------------|--------------|
| 501             | PAGE 9       | 539-1           | PAGE 9       |
| 502-1           | PAGE 9       | 540             | PAGE 9       |
| 503-1           | PAGE 9       | 541             | PAGE 9       |
| 504             | PAGE 10      | 542             | PAGE 4       |
| 505NS           | PAGE 4       | 543             | PAGE 4       |
| 505NS           | PAGE 10      | 543             | PAGE 10      |
| 506             | PAGE 4       | 543-1           | PAGE 4       |
| 506             | PAGE 10      | 544             | PAGE 3       |
| 507A            | PAGE 1       | 545             | PAGE 4       |
| 508-1           | PAGE 9       | 547             | PAGE 9       |
| 509-1           | PAGE 10      | 549-1           | PAGE 4       |
| 510             | PAGE 4       | 549-1           | PAGE 10      |
| 510             | PAGE 10      | 552-1           | PAGE 9       |
| 511             | PAGE 9       | 553             | PAGE 7       |
| 512NS           | PAGE 4       | 557             | PAGE 4       |
| 512NS           | PAGE 10      | 557             | PAGE 10      |
| 513NS           | PAGE 4       | 558             | PAGE 4       |
| 513NS           | PAGE 10      | 558             | PAGE 10      |
| 515NS           | PAGE 4       | 560             | PAGE 4       |
| 515NS           | PAGE 10      | 560             | PAGE 10      |
| 516-1           | PAGE 10      | 561             | PAGE 4       |
| 517-1           | PAGE 4       | 562             | PAGE 4       |
| 518             | PAGE 4       | 563             | PAGE 4       |
| 519             | PAGE 3       | 563             | PAGE 10      |
| 521-1           | PAGE 9       | 601             | PAGE 1       |
| 522             | PAGE 9       | 602             | PAGE 1       |
| 523             | PAGE 9       | 603             | PAGE 1       |
| 524             | PAGE 9       | 604             | PAGE 4       |
| 525A-1          | PAGE 1       | 604             | PAGE 10      |
| 526             | PAGE 9       | 605             | PAGE 4       |
| 527             | PAGE 9       | 606             | PAGE 10      |
| 528             | PAGE 9       | 607             | PAGE 6       |
| 529-1           | PAGE 10      | 608             | PAGE 6       |
| 530             | PAGE 9       | 609             | PAGE 6       |
| 531             | PAGE 9       | 610             | PAGE 7       |
| 532NS           | PAGE 4       | 611             | PAGE 7       |
| 532NS           | PAGE 10      | 612             | PAGE 7       |
| 533-1           | PAGE 10      | 613             | PAGE 7       |
| 534             | PAGE 9       | 614             | PAGE 7       |
| 535             | PAGE 10      | 615             | PAGE 7       |
| 536NS           | PAGE 4       | 616             | PAGE 7       |
| 536NS           | PAGE 10      | 617             | PAGE 7       |

# NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

| <u>PART NO.</u> | <u>PAGE:</u> |
|-----------------|--------------|
| 618             | PAGE 7       |
| 619             | PAGE 7       |
| 620             | PAGE 7       |
| 621             | PAGE 7       |
| 622             | PAGE 7       |
| 623             | PAGE 7       |
| 624             | PAGE 7       |
| 625             | PAGE 7       |
| 626             | PAGE 7       |
| 627             | PAGE 7       |
| 628             | PAGE 7       |
| 629             | PAGE 8       |
| 630             | PAGE 8       |
| 631             | PAGE 8       |
| 632             | PAGE 9       |
| 633             | PAGE 9       |
| 634             | PAGE 9       |
| 635             | PAGE 10      |
| 636             | PAGE 10      |
| 637             | PAGE 10      |
| 638             | PAGE 10      |
| 639             | PAGE 10      |
| 640             | PAGE 10      |
| 641             | PAGE 10      |
| 642             | PAGE 10      |